

Diplomat 2007

Index

A.B

ABS/ATC System (Anti-lock Brakes).....	197
ABS Diagnostic	197
Air Conditioner & Heater Controls	182
System Components.....	184
Troubleshooting	185
Air Mattress (Optional)	108
Select Comfort Air Mattress (Optional)..	108
Air Conditioning - Roof.....	85
AC Service	86
Heat Pump Operation.....	86
Operation.....	85
Return Air Filters	86
Air Dryer.....	192
Air Dryer Cycle.....	194
Desiccant-Type Air Dryer	194
Desiccant Cartridge.....	193
Air Spring Inspections	194
Air Supply System.....	190
Air Governor.....	191
Air Storage Tanks.....	191
Air System Charging (External).....	192
Air Coupler	192
Aladdin™ Engine Display	186
Aladdin™ System (Optional).....	111
Aladdin™ Main Menu.....	112
Aladdin™ Operations.....	112
Coach Info.....	112
Power Down Aladdin.....	113
Select Video Source	113
System Options	113

Time and Alarm Functions.....	113
Trip Meter Selection	113
Voyager Select Button.....	112
Alternator	174
Alternator Testing Procedure	175
Appliances - Introduction.....	74
Awnings.....	102
Awning Care & Cleaning.....	103
Front Door - Mirage.....	102
Patio Awning - Eclipse	103
Slide-out Cover	102
Storm Precautions.....	103
Window Awning.....	102
Backing Up A Motorhome.....	25
Batteries - House	165
Battery Charge Time & Consumption Rate.....	167
Battery Maintenance	165
Testing the Battery	166
Battery - Chassis	172
Battery Cut-out Switch.....	155
Battery Disconnect.....	172
Chassis	172
Battery Disconnect.....	155
House	155
Battery Specification Charts	228
Maintenance Records.....	229
Bedroom Ceiling Fan (Optional)	105
Bedroom Clock Radio With CD/DVD (Optional)	117
Brake Systems	195
Air Brakes.....	195

Automatic Slack Adjuster	196
Brake Systems - Backup	196
Park & Emergency Brake System.....	195
Breaking Camp	28

C.D.E

Carbon Monoxide Detector.....	46
Alarm	48
Cleaning & Maintenance	48
Operation.....	47
Testing.....	48
Ceiling.....	61
Central Vacuum (Optional).....	93
Maintenance.....	93
Operation.....	93
Chassis - Introduction.....	190
Chassis Electrical - Introduction	172
Citizen Band (CB) Radio - Prep	110
Cold Weather Conditions	139
Cold Weather Storage	139
Console	179
Parking Brake.....	180
Shift Selector.....	179
Switches.....	180
Cooktop.....	82
Burner Grate.....	83
Care & Cleaning	83
Cooktop Covers	82

FG

- Cooktop With Oven (Optional)** 83
 Burner Grate..... 84
 Cooktop Covers 83
 Lighting the Burners 84
Coolant System..... 211
 Charge Air Cooler 212
Countertops 64
 Laminate 64
 Solid Surface 64
Dash..... 177
 Indicator Lights 178
 Instrument Panel 177
Dash Radio..... 117
 Operation..... 117
Diagnostic Plug Location..... 185
Disc CD Changer (Optional)..... 117
Distribution Panel..... 164
 House 12 Volt DC 164
Distribution Panel (50 Amp) 161
 Circuit Breaker..... 163
 Energy Management System 162
 GFCI Breakers & Outlets..... 164
 House 120/240 Volt AC Panel 161
Door - Sliding..... 105
Drive Axle & Drive Shaft 202
 U-Joint Angles Phasing &
 Driveline Balance..... 204
Driving & Safety 16
 Familiarize Yourself 16
 Inspections 16
 Mirror Adjust 16
 Safety Seat Belts 16
Driving Tips..... 18
Dry Camping..... 27
**Electric Toilet (40 SKT & 40
 DFT Models Only)** 137
 Cleaning 138
 Drain Traps & Auto Vents 138
- Holding Tank Level Sensors 137
 Maintenance 138
 Operation 137
 Programming the Water Level 137
 Winterization 138
Emergency Roadside Procedures 29
 Dead Chassis Battery 30
 In Case of Flat Tire 30
Engine - General Information..... 208
 Engine "No Start" Flow Chart 187
 Engine Oil 210
Engine Shutdown 210
 Extended Engine Shutdown 211
Entry Door 97
Entry Step 96
 Operation 96
 Step Cover 96
 Stepwell Storage Compartment 97
Equipment - Introduction 96
Escape (Egress) Window 49
Exhaust Brake 213
Exterior Care..... 52
 Bright Metal 54
 Corrosion 52
 Drying 52
 Paint Codes 53
 Tire Care 53
 Washing 52
 Waxing 52
 Wheels - Coated Aluminum 53
**Exterior Entertainment Center
 (Sharp TV Optional)**..... 121
Exterior Maintenance 54
 Fiberglass 54
 Roof Care & Seal Inspections 55
 Sealant Types 55
- Fabrics**..... 57
 General Care & Cleaning 57
 Leather 59
 Ultra-Leather 59
 Vinyl 57
Fans 104
 Automatic 104
 Rain Sensor Fan (Optional) 104
Faucet Screens 132
Fire Extinguisher 48
Floors..... 60
 Carpet Cleaning 60
 Laminate Floor 61
 Tile Floor 61
Free Standing Dinette 109
Front Axle 199
 Alignment 199
 Center Link 201
 Control Arm Bushings 202
 Drag Link 201
 Front Brakes 202
 Lubrication Maintenance Safety 200
 Steering Column 201
 Steering Components 200
 Steering Spindles 201
Fuel System..... 217
 Fuel Filters 219
 Fuel Lines & Hoses 219
 Fuel Requirements 217
 Fuel Sender 218
 Fuel Tank 218
Furnace 86
 If the Furnace Fails to Light 87
 Operation 87
 Using the Furnace 87

- Fuse & Circuits** 172
 Front Distribution Panel 172
 Relays 173
Fuses 165
Generator - 120 AC Diesel 157
 Generator Exercise 160
 Generator Fuel 159
 Powering the Equipment 159
 Pre-Start Checks 158
 Resetting the Circuit Breaker 159
 Starting the Generator 158
 Stopping the Generator 159
Glossary of Terms 5
GPS Navigation (Optional) 110
Grab Handle 97
- H,I,J**
- Height Control Valves** 195
Hitch 22
 Tow Plug Connection 24
 Using the Rear Receiver 22
Home Theatre Surround Sound 118
 Surround Sound Entertainment
 Systems 118
 Surround Sound Entertainment
 Systems (For Motorhomes That Do
 Not Have Bedroom On/Off Switch) 119
 Surround Sound Speaker Switch 118
Home Theatre System 124
House Electrical - Introduction 154
Hydraulic System 220
 Air Filter Minder 221
 Air Intake & Charge Air System 220
 Changing Air Filter 221
 Hydraulic Filter 220
 Hydraulic Reservoir 220
- Interior Care** 57
 Cockpit 57
Inverter 160
 Auto Generator Start (Optional) 161
 Battery Charging with the Inverter 160
 Battery Temperature Sensor 161
 Factory Default Settings 161
 Providing AC Power with Inverter 160
- K,L**
- Keyless Entry (Optional)** 98
 Operation 98
Ladder - Rear 110
**Legless Booth Dinette
 (Not On All Units)** 109
 Bed Conversion 109
Leveling - Hydraulic 205
 Automatic Leveling 207
 Manual Leveling 206
 Prior to Leveling 206
 Retracting Leveling Jacks 207
Lights 169
 Directional Map Lights
 (Not on All Units) 170
 Interior Halogen 169
**Limited Warranty Transfer Application/
 Change of Owner Information** 13
LP-Gas Consumption 151
LP-Gas Detector 144
 Alarm 145
 Maintenance 146
 Testing 145
LP-Gas Distribution Lines 150
- LP-Gas Emergency Procedures**
 Checklist 146
 LP-Gas Fundamentals 148
 LP-Gas Hose Inspection 150
 LP-Gas Regulator 149
 LP-Gas Safety Tips 151
 LP-Gas Systems 144
 LP-Gas Tank 146
 Accessory Hookup 148
 Measurement 146
 Tank Capacity 147
 Tank Filling 147
 Tank Operation 147
Lubrication Charts 225
Lubrication Maintenance 221
- M,N,O**
- Main Slide-out Operation** 98
 Bedroom Slide-Out 100
 Extending & Retracting Slide Rooms 98
 Manual Override 99
 Manual Override 101
 Troubleshooting 99
 Troubleshooting 101
Microwave/Convection Oven 80
 Care & Cleaning 80
Mold & Mildew 66
Owner's Manual Survey: Diplomat 2007 ... 11
- P,Q,R**
- Pest Control** 67
 Rear Vision System 24

Refrigerator	74	J-Lounge (Optional).....	107	Tire Chart - Goodyear.....	34
Air in LP-Gas Supply Lines.....	78	Magic Bed Conversion (Optional).....	107	Tire Pressure Inflation Guideline.....	33
Control Panel - Four Door.....	75	Solar Panel (Optional)	168	Tire Rotation.....	37
Control Panel - Two Door (Optional).....	78	Charge Controller.....	168	Tire Vibration.....	36
Cooling Unit Fans.....	76	Inspection and Maintenance.....	169	Tread.....	37
Doors.....	77	Solar Panel.....	168	Toilet (Not on All Units)	136
Exterior Refrigerator Access Panel.....	77	Solar Panel Care.....	169	Cleaning & Maintenance.....	136
Icemaker.....	76	Specifications Charts	227	Towing Procedures	31
Interior Light.....	77	Belts & Filters.....	227	Disabling Parking Brake.....	32
Operation Specifics.....	74	Chassis Fluid Capacities.....	227	Transfer Switch	157
Refrigerator Alarm.....	76	Engine Specifications.....	227	Transmission	213
Service.....	77	Generator Specifications.....	227	Check Tans Indicator.....	214
Storage Procedures.....	77	Tank Capacities.....	227	Periodic Inspections.....	215
Reporting Safety Defects	4	Stainless Steel Surfaces	64	Transmission Fluid & Filters	216

S.T

Safety Terms	4	Steering Column	175	Satellite System - DSS Prewire.....	116
Satellite	119	Smart Wheel Operation.....	175	Television (Front) Lockout Feature.....	114
In-Motion System (Optional).....	121	Tilt & Telescope.....	176	TV Antenna.....	114
Stationary System (Optional).....	119	Wiper Function.....	176	Video Selector Box.....	115
Satellite Radio (Optional)	111	Steering Gear	202		
Seat Controls	106	Storage	69		
Set-Up Procedures	26	Long Term.....	69		
Shock Absorber	205	Removal from Storage.....	71		
Shore power Hook-up	155	Short Term.....	69		
Manual Cord Reel.....	157	Winter Storage Checklist.....	71	Vendor List	7
Power Cord Reel (Optional).....	157	Storage Bay Slide-out Tray	110		
Shower	61	Storage Under Bed	110		
Smoke Detector	46	Sunvisors	105		
Maintenance.....	46	Swivel Seats.....	106		
Operation.....	46	Systems Control Center	123		
Testing.....	46	Tires	32	Wall Coverings	62
Troubleshooting.....	46	Air Pressure Checklist.....	36	Wall Thermostat.....	85
Sofa	106	Importance of Air Pressure.....	33	Warranty Information File	4
Easy Bed Sofa.....	106	Inspecting & Pressure.....	35	Warranty Limited: 2007 Monaco	i
Hide-A-Bed (Optional).....	107	Storage of Tires - Long Term.....	37	Warranty Limited: 2007 Roadmaster	iii
		Supporting When Leveling.....	36		

U.V

W.X.Y.Z

Washer/Dryer (Optional)	91	Window Treatments	65
Operation	91	Day/Night Shades	65
Washer/Dryer Maintenance	92	Mini-Blinds	65
Winterizing the Washer/Dryer	93	Winterization	139
Washer/Dryer Prepared	90	Dewinterization	141
Waste Pump (Optional)	134	Using Air Pressure	139
Waste Water Systems	132	Using Non-Toxic Antifreeze and Gravity Fill	140
Proper Waste Disposal	132	Wiring Diagram -	124
Tank Flush	134	Wood Care	62
Waste Drain Hose	133		
What Not to Put in Waste Holding Tanks	132		
What to Put in Holding Tanks	133		
Water Filter - Faucet	130		
Water Heater	88		
Water Pump	129		
Water Pump Troubleshooting	130		
Water Service Center	142		
Water Systems	131		
Disinfecting Fresh Water	131		
Troubleshooting	131		
Water Systems - Introduction	128		
Water Tank - Fresh Gravity Fill	129		
City Water Hook-up	129		
Water Tanks	128		
Fresh Water Fill	128		
Measurements & Calibration	128		
Weighing the Motorhome	38		
Cargo Carrying Capacity Flowchart	43		
Four Corner Weighing (Example)	41		
Weighing Procedure Worksheet	44		
Weight Label	40		
Weight Record Sheet	45		
Weight Terms	38		
Wheel Mounting	37		
Windows	64		
Condensation	65		

